

## Config HF680 – Rev 2

- 1) Set scanner to USB serial



TERMID130.

**USB Serial**

- 2) Add CR Suffix



VSUFCR.

**Add CR Suffix  
All Symbologies**

- 
- 3) Optional – only when scanning QR from screen – not support for paper



ILLMOD2.

**Screen Only Read Mode**

- 4) Optional – remove custom settings



DEFOVR.

**Remove Custom Defaults**

- 5) Activate default setting



DEFAULT.

**Activate Defaults**